### END IDLING IN YOUR FLEE

#### ENGINES CAN'T POLLUTE AT ZER

EM100E48V

#### **SYSTEM BENEFITS:**

- IMPROVE OPERATOR SAFETY
- ENGINE-OFF AIR CONDITIONING
- REDUCE OPERATING COST
- PROTECT THE ENVIRONMENT
- LIGHT WEIGHT
- SMALL FORM FACTOR

#### **SPECIFICATIONS:**

5.12 kWh Total Energy Usable Energy 4.00 kWh **Current Limit Export** 250A @ 100% Duty Cycle @48V 48V-56.4V **Export Voltage** Charge Voltage 48V-56.8V Nominal Voltage 51.2V Lithium-Iron (LiFeMnPO4) **Battery Chemistry** Internal Fuse Rating Battery Protection (Slow Blow) 300A **Product Housing Material** Powder-coated Galvanized Steel and Aluminum ~140 lbs / ~63.5 kg Weight 32°F to 150°F / 0°C to 65.6°C Charging Temperature Range\* **Discharge Temperature Range\*** -4°F to 150°F / -20°C to 65.6°C Number of 12V Battery Packs 4

**6" CLEARANCE NEEDED FOR** CONNECTIONS 26.3Ź 12.00

\*Temperatures are based on software versions 4.94.00 and later with battery SOC of >40%.

#### Ask for ZeroRPM® Idle Mitigation Systems® WHERE you purchase your fleet vehicles!

ZeroRPM energy modules are a safe and space efficient solution when you want to add lithium power to your vehicle. This module is designed to power lights, radios, computers, inverters and other electronics with your engine off. Energy Modules of the same voltage may be added in parallel to increase the run time of your system. Energy modules contain an on-board battery management system. ZeroRPM energy modules use lightweight \*lithium-iron batteries. This chemistry makes ZeroRPM battery technology among the safest on the market. This unit can be charged using 48V power from an alternator, solar panels, or other 48V power source.


Note: This product requires other ZeroRPM IMS components. Reference ZeroRPM.com/systems for more information.

\*"Lithium-Iron" is marketing term for ZeroRPM's LiFeMnPO4 packaged energy storage systems.

# 10.63



## END IDLING



#### **PRODUCT NOTES:**

-Storage temperature: -4 °F to 149 °F / -20 °C to 65 °C.

-The unit must be mounted securely and upright.

-In shipping or storage, do not stack more than one product on top of one another (i.e. two unit stack maximum).

-The unit must be mounted so the lid is removable.

-The unit must be mounted as closely to the loads and supply as possible.

-If the unit has been in storage for more than 90 days, the voltage must be checked to ensure that the batteries have not discharged past the acceptable threshold.

-There must be adequate provisions for drainage below the unit to prevent flooding.

-There must be at least 6" of clearance on the right side of the unit for the main power connectors.

-The unit must be mounted in a well-ventilated compartment. In extreme hot or cold environments, it is ideal to mount the unit in a temperature controlled compartment.

-The unit must be mounted with vibration-dampening material. The material must be installed between the unit's feet and the mounting surface.

-Exporting at maximum current for an extended amount of time will substantially reduce the life of the battery pack.

-Do not put the unit on its side or upside down without written approval from ZeroRPM.

-Do not extend the current shunt wires (if current shunt wires are present).